



How to change the combination?

*The initial combination is 0000.

*Press and hold the red button, then set the desired new combination.

*Remember the new combination!

*Release the red button, press and hold the silver button, pull down the side plate, and the combination will be changed successfully.



How to unlock?


Set the correct combination, press and hold the silver button and at the same time pull down the side plate.

How to lock?

*Press and hold the silver button, insert the side plate into the lock.
*Pull the side plate to ensure the lock is locked.

Installation Method:

Attach the folding lock to the bike beam using the mounting material in the kit as shown.



WEISER



Comment changer la combinaison?

*La combinaison initiale est 0000.

*Appuyer et maintenir le bouton rouge, puis régler la nouvelle combinaison désirée.

*Retenir la nouvelle combinaison!

*Relâcher le bouton rouge, appuyer et maintenir le bouton argenté, tirer la plaque latérale vers le bas, et la combinaison sera changée avec succès.



Comment déverrouiller?


Régler la combinaison correcte, appuyer et maintenir le bouton argenté et, en même temps, tirer la plaque latérale vers le bas.

Comment verrouiller?

*Appuyer et maintenir le bouton argenté, insérer la plaque latérale dans le cadenas.
*Tirer sur la plaque latérale pour s'assurer que le cadenas est bien verrouillé.

Méthode d'installation:

Fixer l'antivol pliant au tube du cadre du vélo à l'aide du matériel de montage fourni dans la trousse, tel qu'illustré.



WEISER